# **OMNIRES**

## MARINA | walk-in shower enclosure with side wall, 100 x 30 cm

### Finish: matt black / transparent glass (BLMTR)

Black support arm may be shortened to the desired length and mounted on the opposite wall.

Certificates: European Declaration of Performance (CE marking)



# **Technologies**



Tempered safety glass with the innovative 3M™EASY CLEAN coating prevents water and dirt build-up and is easy to clean.



Thanks to the DUAL MOUNT system, shower enclosure may be installed on either side.

## Flow characteristics

• working pressure 1-5 bar

# Specification

wall: 100 cmside wall: 30 cm

• support arm: max 120 cm

• height: 200 cm

• tempered safety glass, thickness: 8 mm

• aluminium profiles, profile adjustment: -0.7/+0.3 cm

• black support arm may be shortened to the desired length

### Product care

#### What is the most effective way to clean a shower enclosure?

The glass walls of the shower enclosure should be cleaned regularly, preferably after each use, using a soft cloth (for example, a microfibre cloth) and a solution of water with a mild cleaning agent with a natural composition. After cleaning the enclosure, rinse the inner glass surface thoroughly and remove any remaining water with a rubber squeegee or soft cloth. You can clean the outer side of the glass walls using a mirror or glass cleaner. It is important to avoid using rough, abrasive materials and caustic or bleaching substances to prevent damaging the surface of the glass.

To tackle stubborn dirt or limescale deposits, you can use cleaning agents dedicated to shower enclosures. It is recommended to lubricate hinges, joints, guide tracks and rollers at least once a year using technical lubricant or silicone grease to ensure their smooth operation.

