

## DAVIS | wall-mounted shower column

---

Finish: polished chrome (CR)



## Technologies

---



Developed to minimise environmental footprint, the ECO WATER technology reduces water consumption by approx. 30% without compromising on the overall product experience.



The EASY CLEAN nozzles allow the user to easily remove any limescale build up by simply wiping their silicone surface.



The shower head is made using the ANTI-SCALE technology. It incorporates a silicone insert that prevents internal water stagnation. Occasional tilting of the shower head, so that any stagnant water could flow out through the nozzles, guarantees long term product performance.



The product's coating, made using advanced galvanization technology, is durable and easy to clean.

## Flow characteristics

---

- working pressure 1-5 bar

## Specification

---

- to be mounted with any shower or bath mixer for exposed installation
- shower column (UN10041CR) with brass diverter and arm for mounting shower head
- distance between mounting brackets: 73.2 cm
- stainless steel shower head (WGU225CR), dimensions: 25 x 25 cm, arm reach from the wall: ~40 cm
- hand shower (DAVISX-RCR), 3-function, streams: rain, massage, mixed
- stainless steel flexible shower hose, length: 150 cm
- connecting hose for shower mixer
- swivel arm
- total system height: 83.5 cm/114 cm (adjustable)

## Product care

---

### What is the best way to care for a hand shower ?

Remember to regularly wipe the silicone nozzles with your hand to remove any limescale deposits that might be forming on their surface. A toothpick or toothbrush can also be used to clean the spaces in between if there is a considerable build-up of limescale.

For more stubborn dirt, it is recommended to immerse the hand shower in a 10% citric acid solution with water for about 10 minutes to soften the limescale and then wipe across the nozzles with a soft brush. It is not recommended to use rough or abrasive materials and corrosive or bleaching substances to prevent damaging the surface of the product. From time to time, it is recommended to unscrew the hand shower and flush it from the inside to remove any dirt preventing the flow of water.