

VITA | kitchen tap with pull-out spout

Finish: brushed graphite / matt black (GR)

The OMNIRES VITA kitchen tap combines perfect form with maximum functionality. Its contemporary, minimalist form is shaped by the geometry of the arch, resulting in a silhouette that feels both light and visually balanced. The swivel spout, equipped with a pull-out spray function, can be detached to direct the water stream precisely where needed. A flexible black rubber part of the spout enhances ease of use, while the tap's optimal height adds to everyday convenience. The model is equipped with a superior quality ceramic cartridge and innovative technologies that help reduce water consumption by 50% while offering comfort and ease of use.

Graphite is an intriguing finishing in the shade of metallic grey, with a satin, brushed surface.

Certificates: Polish Declaration of Performance (B marking), Polish Hygienic Certificate PZH



Technologies



The mixer is equipped with the highest quality ceramic cartridge which ensures smooth and precise water flow control whilst guaranteeing long term product performance.



The ECO WATER technology minimizes environmental footprint by reducing the water consumption by approx. 50%, without compromising on the overall product experience.



Thanks to the AIR WATER technology, the water is soft and pleasant to the touch. The stream does not spray and it is quiet and consistent, even if any variations in water pressure occur.



The swivel pull-out spout allows precise control of the water flow, makes filling pots and containers easier, and ensures complete freedom of movement at the sink.

Flow characteristics

- hot water supply: max. 90 °C
- working pressure 1-5 bar
- water flow at 3 bar: 8.39 l/min
- acoustic group: I

Specification

- detachable spout
- swivel spout
- spout reach: 22.2 cm
- water outflow height: 23.5 cm
- total mixer height: 42.3 cm
- 1-function hand shower

Product care

How to take care of bathroom and kitchen fittings?

You should clean your bathroom and kitchen fittings regularly, preferably after each use, so as to prevent the build-up of hard-to-remove dirt. For daily maintenance of external surfaces, use a soft cloth (for example, a microfibre cloth) and a solution of water with a mild cleaning agent with a natural composition, then rinse the product thoroughly with clean water and wipe it dry. It is not recommended to use rough or abrasive materials and corrosive or bleaching substances to prevent damaging the surface of the product.

For more stubborn dirt, use a 10% citric acid solution with water. Apply this solution directly to the product or cover the product with a cloth soaked in the solution. After 10 minutes, rinse the product thoroughly with clean water and wipe it dry. If necessary, the process can be repeated.

What is the best method for cleaning the aerator?

Remember to regularly control the flow of water through the aerator so as to ensure its problem-free operation and protect it from damage. In the case of small contaminants in the water or "hard" water, remove the aerator once every few weeks and clean it with a brush. In the case of more stubborn dirt, we recommend soaking the aerator for 10 minutes in a 10% citric acid solution with water.

