OMNIRES

filter cartridge | D1 filter cartridge

Finish:

The advanced technological solutions used in the Dafi filter cartridge guarantee water of the highest quality. The filter cartridge, with its activated carbon and resin technology, lowers the hardness of the water and reduces its content of chlorine and heavy metals, supplying pure and flavoursome drinking water additionally enriched with potassium.

For a family of four, where each person drinks around 1.5 litres of water a day, the water filter will last between 2.5 and 8 months, depending on the hardness of the tap water. For this reason, it is important to set the appropriate water hardness level of the filter cartridge in order to guarantee the best quality water throughout its service life.



Specification

- replacement filter cartridge for the filtering system of the OMNIRES SWITCH kitchen tap
- reduces the content of chlorine and heavy metals
- lowers the hardness of the water

Product care

How to take care of bathroom and kitchen fittings?

You should clean your bathroom and kitchen fittings regularly, preferably after each use, so as to prevent the build-up of hard-to-remove dirt. For daily maintenance of external surfaces, use a soft cloth (for example, a microfibre cloth) and a solution of water with a mild cleaning agent with a natural composition, then rinse the product thoroughly with clean water and wipe it dry. It is not recommended to use rough or abrasive materials and corrosive or bleaching substances to prevent damaging the surface of the product.

For more stubborn dirt, use a 10% citric acid solution with water. Apply this solution directly to the product or cover the product with a cloth soaked in the solution. After 10 minutes, rinse the product thoroughly with clean water and wipe it dry. If necessary, the process can be repeated.

What is the best method for cleaning the aerator?

Remember to regularly control the flow of water through the aerator so as to ensure its problem-free operation and protect it from damage. In the case of small contaminants in the water or "hard" water, remove the aerator once every few weeks and clean it with a brush. In the case of more stubborn dirt, we recommend soaking the aerator for 10 minutes in a 10% citric acid solution with water.

