Product code: YOSEMITE-SCR
EAN: 5901867778987

OMNIRES

YOSEMITE | sliding shower set

Finish: polished chrome (CR)

The OMNIRES YOSEMITE collection stands out for its multifunctionality, offering features that enhance everyday comfort. The hand shower offers five types of water stream – massage, mist, aerated rain, aerated massage, and aerated mist – allowing the product to be tailored to individual needs and preferences. Its universal, rounded design and wide colour palette make it a perfect fit for contemporary bathroom aesthetics. The shower set, equipped with an adjustable holder, enables effortless hand shower's height adjustment during use.

Chrome is a versatile finishing in a silvery colour, with the perfectly even and lustrous surface.

Certificates: Polish Declaration of Performance (B marking)



Technologies

The EASY CLEAN nozzles allow the user to easily remove any limescale build up by simply wiping their silicone surface.

Flow characteristics

- water flow at 3 bar: 5 l/min
- hot water supply: max. 90 °C
- working pressure 1-5 bar

Specification


- hand shower, 5-function, streams: massage, mist, aerated rain, aerated massage, aerated mist
- stainless steel sliding bar, length: 82.5 cm, distance between mounting brackets: 74.3 cm
- stainless steel flexible shower hose, length: 150 cm

Product care

WHAT IS THE BEST WAY TO CARE FOR A HAND SHOWER ?

Remember to regularly wipe the silicone nozzles with your hand to remove any limescale deposits that might be forming on their surface. A toothpick or toothbrush can also be used to clean the spaces in between if there is a considerable build-up of limescale.

For more stubborn dirt, it is recommended to immerse the hand shower in a 10% citric acid solution with water for about 10 minutes to soften the limescale and then wipe across the nozzles with a soft brush. It is not recommended to use rough or abrasive materials and corrosive or bleaching substances to prevent damaging the surface of the product. From time to time, it is recommended to unscrew the hand shower and flush it from the inside to remove any dirt preventing the flow of water.


154
60
34
102
262
∅40
122
1022
∅25
L=1500