

CALGARY | wall-mounted shower column

Finish: polished chrome (CR)



Certificates: Polish Declaration of Performance (B marking)

Technologies



The ECO WATER technological solutions minimise environmental footprint by reducing water consumption by 30-50% without compromising on the overall product experience.



The EASY CLEAN nozzles allow the user to easily remove any limescale from the shower head and the hand shower by simply wiping their silicone surface.



The shower head is made using the ANTI-SCALE technology. It incorporates a silicone insert that prevents internal water stagnation. Occasional tilting of the shower head, so that any stagnant water could flow out through the nozzles, guarantees long term product performance.

Flow characteristics

- working pressure 1-5 bar

Specification

- to be mounted with any shower or bath mixer for exposed installation
- shower column (UN10041CR) with brass diverter and shower head arm
- distance between mounting brackets: 73.2 cm
- stainless steel shower head (WGU120CR), dimensions: ø20 cm, arm reach from the wall: 43 cm
- hand shower (YOSEMITE-RCR), 5-function
- stainless steel flexible shower hose, length: 150 cm
- connecting hose for shower mixer
- swivel arm
- adjustable height, minimum/maximum system height: 83.5 cm/114 cm

Product care

How to take care of a shower head?

Remember to regularly wipe the silicone nozzles with your hand to remove any limescale deposits that might be forming on their surface. Avoid using harsh cleaning agents that may damage the nozzles and the surface of the shower head.

The shower head should be angled after each use to allow the remaining water to flow out. This is the easiest yet necessary way to reduce the build-up of limescale from the water inside the shower head. Tilting the shower head additionally reduces the risk of the product becoming prone to leaking, allowing the product to serve its purpose reliably for an extended time.

What is the best way to care for a hand shower ?

Remember to regularly wipe the silicone nozzles with your hand to remove any limescale deposits that might be forming on their surface. A toothpick or toothbrush can also be used to clean the spaces in between if there is a considerable build-up of limescale.

For more stubborn dirt, it is recommended to immerse the hand shower in a 10% citric acid solution with water for about 10 minutes to soften the limescale and then wipe across the nozzles with a soft brush. It is not recommended to use rough or abrasive materials and corrosive or bleaching substances to prevent damaging the surface of the product. From time to time, it is recommended to unscrew the hand shower and flush it from the inside to remove any dirt preventing the flow of water.

